

READ CAREFULLY!

STEPS FOR A NEW INSTALLATION:

- FIRST, REMOVE THE ADHESIVE REMAINS FROM THE ACCESSORY AND FROM THE WALL WITH ALCOHOL.

- PRESS **THE FIRST 3M STICK** ON THE CENTER, APPLY IT ON THE PLATES THAT SUPPORT THE ACCESSORY AND HEAT THEM WITH A HAIRDRYER TO DRY UP THE LIQUID (PRIMER).

- HEAT THE ADHESIVE AND THE PLATE WITH A HAIR DRYER, PRESS THE ADHESIVE AGAINST THE PLATE WITH A CYLINDRICAL SURFACE. **YOU MUST WAIT 72 HOURS BEFORE PLACING THE ACCESSORY ON THE WALL.**

** FROM HERE YOU FOLLOW THE NORMAL INSTALLATION PROCESS (Please check out your installation instructions included.)*

- CLEAN THE SURFACE WHERE YOU WANT TO PLACE YOUR ACCESSORY WITH ALCOHOL AND DRY IT WITH A CLEAN CLOTH.

- WE RECOMMEND BEFORE PLACING THE ACCESSORY, MARK IT ON THE WALL FOR A PERFECT INSTALLATION.

- APPLY A **SECOND 3M STICK** (PRIMER) ON THE SURFACE WHERE YOU WANT TO PLACE THE ACCESSORY, PRESSING THE CENTER OF THE 3M STICK UNTIL THE LIQUID COMES OUT. WAIT UNTIL IS COMPLETELY DRY. (REMEMBER THE STICK IS NOT AN ADHESIVE)

- REMOVE THE ADHESIVE PROTECTIVE PAPER FROM THE 3M ADHESIVE WITHOUT TOUCHING IT WITH YOUR FINGERS.

- HEAT THE ADHESIVE (WITH A HAIR DRYER) UNTIL YOU NOTICE IT'S SOFT AND/OR THE PLATE IS HOT. HEAT THE WALL AS WELL.

- PRESS HARD AGAINST THE WALL FOR 1 MINUTE THROUGHOUT THE WHOLE PLATE SURFACE.

- **DO NOT PUT ANY WEIGHT OR USE THE ACCESSORY FOR AT LEAST 72 HOURS. DO NOT USE THE SHOWER IN ORDER TO AVOID HUMIDITY.**

** IF YOU HAVE ANY DOUBT, PLEASE CONTACT US: 965 81 77 72 / bdonline@banodiseno.com*